





TOP SPEED 50 KMH / 30 MPH



BATTERY RANGE 55+ KM / 34+ MI



TIRES 10" Tubeless Offroad Tires



MOTOR Dual 52V 1000W (2000W Total)



POWERFUL DUAL 1000W MOTORS

The Cyclone is an exciting new Dual 1000W (2000W total) electric scooter from Synergy. The Cyclone comes standard with our new 10" Tubeless Offroad Tires! Our Anti-theft voltage lock key and standard signal lights are added safety feature that take the Cyclone to the next level.

Make it yours! All Cyclone models include LED sidelights on the deck and upright. Download our app and choose from hundreds of different colour settings.

Suggested MAX weight of rider to be 250lbs

TECH SPECIFICATIONS

MOTOR Dual 52V 1000W (1000W in Single Mode / 2000W in Dual Mode)	TIRES 10" Tubeless Offroad Tires	SCOOTER DIMENSIONS - OPENED 49.2" L x 8" W x 50.8" H (Inches) 125L x 20.5 W x 129 H (CM)
BATTERY 52v 20.8AH Lithium Battery	WATER RESISTANT Yes, this model is rated IP54. IP54 products are protected against water splash from all angles and heavy rain. If immersed fully in water, the product will be damaged.	SCOOTER DIMENSIONS - CLOSED 49.2" L x 8" W x 20.6" H (Inches) 125 L x 20.5 W x 52.5 H (CM)
TOP SPEED 32 KMH / 20 MPH by display Can be unlocked to 50 KMH/30 MPH for offroad use Check local regulations before unlocking.	GRADE ABILITY 25 to 30 Degree	LIGHTS Head light / Brake Light / Signal Lights / LED Sidelights on Deck and Stem (with App)
BATTERY RANGE Approx. 55km-75km. (34-47 mi) Range depends on many factors such as terrain, riders weight, riding style, dual or single mode.	BRAKES Front and rear disc brake + electric brake	TEMPERATURE RANGE Working Temp: -5°C~40°C (14F-104F) Storage Temp: -5°C~40°C (14F-104F)
CHARGER INPUT: 100-240V~50/60HZ OUTPUT: 58.8V===2.0A	SUSPENSION Front and rear spring suspension	FOLDING MODEL Yes, this model folds
CHARGE TIME 7 hrs	FRAME Aluminum Alloy	ANTI-THEFT Voltage Lock Key
SCOOTER WEIGHT 35kg / 77lbs	SPEEDOMETER Smart LCD display	RIDER MINIMUM AGE / SIZE RANGE 16 years old (between 150-215 cm)



BATTERY

The battery is the main energy source of your SYNERGY CYCLONE, so be sure to treat it with care at all times. We recommend that your recharge it only with the charger provided with your SYNERGY CYCLONE.

BATTERY FUNCTIONS

- 1. There are three key positions on, locked and unlocked.
- 2. When the key is turned to the **unlocked** position, the battery ready to be removed.
- 3. In the **locked** position (which can be found by turning the key one click from the unlocked position), the battery cannot be removed, and motor cannot be switched on.
- 4. In the **on** position (which can be found by turning the key two clicks from the unlocked position), you have full use of your bike's electronic components. When the key is in the **on** position, turn the motor and LCD screen on and off by pushing the power button on the display.