



SYNERGY TSUNAMI

MODEL NUMBER
SYN-TD1200



TOP SPEED

Up to 60 KM / 37
MPH (offroad)



BATTERY RANGE

60+ KM / 55+ MI



TIRES

10" Tubeless Offroad Tires



MOTOR

Dual 60V 1200W
(2400W Total)



ANTI-THEFT

Voltage Lock Key

POWERFUL DUAL 1200W MOTORS

The Tsunami is an exciting new Dual 1200W (2400W total) electric scooter from Synergy. The Tsunami comes standard with our new 10" Tubeless Offroad Tires! Our Anti-theft voltage lock key and standard signal lights are added safety feature that take the Tsunami to the next level.

Make it yours! All Tsunami models include LED sidelights on the deck and upright. Download our app and choose from hundreds of different colour settings.

Suggested MAX weight of rider to be 250lbs

TECH SPECIFICATIONS

MOTOR Dual 60V 12 00W (1200W in Single Mode / 2400W in Dual Mode)	TIRES 10" x 2.75" Tubeless Offroad Tires	SCOOTER DIMENSIONS - OPENED 51.3" L x 8" W x 51.2" H (Inches) 130.5L x 20.5 W x 130 H (CM)
BATTERY 60V 24Ah Lithium Ion Battery	WATER RESISTANT Yes, this model is rated IP54. IP54 products are protected against water splash from all angles and heavy rain. If immersed fully in water, the product will be damaged.	SCOOTER DIMENSIONS - CLOSED 51.3" L x 8" W x 20.9" H (Inches) 130.5 L x 20.5W x 53H (CM)
TOP SPEED 32 KMH / 20 MPH by display Can be unlocked to 60 KMH/37 MPH for offroad use Check local regulations before unlocking	GRADE ABILITY 25 to 30 Degree	LIGHTS Head light / Brake Light / Signal Lights / LED Sidelights on Deck and Stem (with App)
BATTERY RANGE Approx. 60km-90km. (37-56 mi) Range depends on many factors such as terrain, riders weight, riding style, dual or single mode	BRAKES Front and rear drum brake + electric brake	TEMPERATURE RANGE Working Temp: -5°C~40°C (14F-104F) Storage Temp: -5°C~40°C (14F-104F)
CHARGER INPUT: 100-240V~50/60HZ OUTPUT: 67.2V===2.0A	SUSPENSION Front and rear spring suspension	FOLDING MODEL Yes, this model folds
CHARGE TIME 10 hrs	FRAME Aluminum Alloy	ANTI-THEFT Voltage Lock Key
SCOOTER WEIGHT 40 kg / 88 lbs	SPEEDOMETER Smart LCD display	RIDER MINIMUM AGE / SIZE RANGE 16 years old (between 150-215 cm)



BATTERY

The battery is the main energy source of your SYNERGY TSUNAMI, so be sure to treat it with care at all times. We recommend that you recharge it only with the charger provided with your SYNERGY TSUNAMI.

BATTERY FUNCTIONS

1. There are three key positions — **on**, **locked** and **unlocked**.
2. When the key is turned to the **unlocked** position, the battery is ready to be removed.
3. In the **locked** position (which can be found by turning the key one click from the unlocked position), the battery cannot be removed, and the motor cannot be switched on.
4. In the **on** position (which can be found by turning the key two clicks from the unlocked position), you have full use of your bike's electronic components. When the key is in the **on** position, turn the motor and LCD screen on and off by pushing the power button on the display.